

HQD Car Stereo Software Updating Guide.

1. Prepare a U disk with a size of 4G or more and less than 32G. (You can back up the U disk files first.)

2. Format the U disk. Make sure the file system was chosen **FAT32**. (**This is very important!**)


3. Unzip the downloaded file.

4. Copy the file "XXXXXX.BIN" to the formatted U disk (root directory).

5. Start your car to start the car stereo.

6. Insert the U disk to the car stereo. The car stereo would reboot automatically.

Seconds later then the screen would show updating information. Just wait for the updating, do not stop the car stereo or cut off the power during updating. It may take about 3-5 minutes. (If the car stereo does not reboot after a long time waiting after inserting the U disk, it means that the U disk is not suitable for the updating, and you need to change another one. Remove the car key to turn off the car stereo, or use a card pin to press the reset button of the car stereo. Then repeat the steps above.)



7. Update complete, the car stereo would reboot automatically. Then press the reset button to reset the radio. Or you can turn the car off to turn the radio off and then turn the car on to turn the radio on.